

brennenstuhl®

Scannen für detaillierte Anleitung

Scan for detailed guide

Scanner la notice d'utilisation détaillée

Scan voor gedetailleerde handleiding




- DE** Kurzanleitung
- EN** Quick guide
- FR** Guide de configuration rapide
- NL** Snelle handleiding
- IT** Guida veloce
- SE** Instruktionsguide
- ES** Instrucciones rápidas
- PL** Skrócony przewodnik

- CZ** Rychlý průvodce
- HU** Gyorsútmutató
- RU** Краткое руководство
- TR** Çabuk kılavuz
- FI** Pikaopastus
- GR** Γρήγορος οδηγός
- PT** Guia depressa
- EE** Kiire juhend

- SK** Rýchly sprievodca
- SI** Kratek vodnik
- LT** Trumpasis vadovas
- LV** Ātrā rokasgrāmata
- RO** Ghid de scurtă durată
- BG** Бързо ръководство



LuxPremium Akku LED Sensor Kopflampe SL 500 A



1



1x red light
2x flashing red light
3x off




2

1x 100%
2x 40%
3x 10%



3 sec.
→ sensor mode on
3 sec.
→ sensor mode off



Sensor



Hugo Brennenstuhl GmbH & Co. KG · Seestraße 1-3 · D-72074 Tübingen

lectra technik ag · Blegistrasse 13 · CH-6340 Baar

H. Brennenstuhl S.A.S. · 4 rue de Bruxelles · F-67170 Bernolsheim

Brennenstuhl UK Ltd. · No 1 Royal Exchange · London EC3V 3DG, UK

www.brennenstuhl.com

service.brennenstuhl.com

0534400/724